


# PARTS OF A TRACTOR



HARTPURY



Flashing Beacon	Mirror	Exhaust pipe
Radio aerial	Steering wheel	Work lights
Wheel rim	Engine	Rear axle
Gearbox	Front Axle	Tyre
Hydraulic steering ram	Engine Cooling fan	Radiator
Headlights and work		Detachable front weights